

# BLE Locking Standard 2 Module

Quick start guide



1

## Before you start

Choose a suitable installation place for the module. An ideal installation place for the BLE Locking Standard 2 module is in close proximity to the lock. Its size allows the installation into an EU round wall socket box.




**Note:** Electrical connections should be done by electricians.

### In the box:

1. BLE Locking Standard 2 module





## Physical properties


**Dimensions:**  $\varnothing = 49.6\text{mm}$ ,  $h = 19.0\text{mm}$

**Weight:** 25g

**Working temp.:**  $-40^{\circ}\text{C}$  up to  $75^{\circ}\text{C}$

**IP rating:** IP41

**Mounting:** Fits inside an EU electrical 60mm wall socket box.




## Install Standard 2 module

There are two connection options. The relay can be connected either as a power-free relay switch (NC) for garage doors and car gates or with supply power for door locks, magnets and strike plates.




**Note:** Sample electrical connection drawings and LED indication description on next sheets.







# Install Standard 2 module

## LED indication




## 12VDC Power Source







# Install Standard 2 module


## Wiegand card reader/PIN pad (optional)






## Install Standard 2 module






## Install Standard 2 module



The module is installed into a garage door actuator box where the relay is connected to “open door” button terminals.



The module is installed into a car gate actuator box where the relay is connected to “open gate” button terminals.

3

## Activate module


**Step 1:** Download the **BLE Locking App** to your smartphone from the App Store (Apple) or the Google Play Store (Android).



**BLE Locking**


Activate module

**Step 2:** Tap **Register** to create an account in the app and log in.




Activate module

**Step 3:** Tap **Add new** and scan the QR-code that came with the module.



Activate module

**Done:** You are ready to use your lock.  
The lock is activated when you tap the **lock icon**.



## Good to know

### Operation

A connection between the lock and the app is established over Bluetooth connectivity.

### Range

To operate the lock, the smartphone (BLE Locking app) needs to be in the Bluetooth range. Range is higher in environments with direct visibility (~50m) and lower where there is no direct visibility to the lock.

### Purchasing digital keys

Your module might come with a set of keys included in the module price. Additional keys may be acquired from your reseller or via the BLE Locking app.

## **Power failure**

After power failure, the BLE Locking Standard module will continue the operations as soon as power supply is restored. To operate the lock during power failure, a relevant backup battery needs to be connected to the module and the lock.

## **Loss of your phone**

In case your mobile phone gets lost, all keys may be revoked via the BLE Locking web admin portal. You may generate new keys for the lock as soon as you have downloaded the BLE Locking app into your new phone and logged in to the app.



# Technical specification

<b>Power Supply</b>	12VDC
<b>Relays (Quantity &amp; type)</b>	1x non-latching max. load 10A 240VAC or max. load 10A 12VDC
<b>Radio protocols &amp; network</b>	Wi-Fi 802.11 b/g/n Bluetooth v4.2 BR/EDR & BLE Ext. WiFi/BT antenna (optional)
<b>Additional connectivity</b>	1x Wiegand reader or 2x analogue inputs for hardware switch / PIR sensor / Hall-effect sensor 1x open collector output
<b>Physical connectors</b>	Relay in / out, power, input switch 7-gang terminal for cables up to 1 mm <sup>2</sup>
<b>IP rating</b>	IP41
<b>Electrical consumption</b>	Normal operation 50 mAh Maximum 200 mAh
<b>Working temp.</b>	-40°C up to 75°C
<b>Weight</b>	25g



we put our  in locking

Customer support  
**support@blelocking.com**

Sales  
**sales@blelocking.com**

More information  
**blelocking.com**

